



150M Wireless-N Broadband Router

Model No.: iB-WRB150N



User Manual

Ver.: 1.0.0

FCC STATEMENT



This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio / TV technician for help.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:

- 1) This device may not cause harmful interference.
- 2) This device must accept any interference received, including interference that may cause undesired operation.

Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

CE Mark Warning



This is a class B product. In a domestic environment, this product may cause radio interference, in which case the user may be required to take adequate measures.

Table of Contents

Table of Contents.....	3
Chapter 1 Product Overview	5
1.1 Package Contents.....	5
1.2 Panel Overview.....	6
Chapter 2 Installation.....	8
Chapter 3 Internet Connection Setup	10
3.1 Configure your PC's TCP/IP Settings.....	10
3.2 Login to Router	15
3.3 Quick Internet Connection Setup.....	16
3.4 Quick Encryption.....	17
Chapter 4 Network Settings	18
4.1 Status Info.....	18
4.2 WAN	19
4.2.1 PPPoE	19
4.2.2 Static IP.....	21
4.2.3 Dynamic IP.....	21
4.3 LAN	24
4.4 MAC Clone	25
4.5 DNS.....	26
4.6 Bandwidth Control.....	27
4.7 Traffic Statistics	29
4.9 WAN Speed	30
Chapter 5 Wireless Settings.....	32
5.1 Wireless Basic Settings.....	32
5.2 Wireless Security	37
5.2.1 WPS Settings.....	37
5.2.2 WPA-PSK.....	38
5.2.3 WPA2-PSK.....	39
5.2.4 WEP.....	39
5.3 MAC Filtering	39
5.4 Connection Status	42
Chapter 6 DHCP	43
6.1 DHCP Settings.....	43
6.2 DHCP Clients & Address Reservation.....	44

Chapter 7 Virtual Server	45
7.1 Port Forwarding	45
7.2 DMZ.....	47
7.3 UPnP	48
Chapter 8 Security Settings	49
8.1 IP Address Filtering	49
8.2 MAC Address Filtering.....	50
8.3 URL Filtering.....	53
8.4 Remote Management.....	54
Chapter 9 Routing Settings	56
9.1 Routing Table	56
9.2 Static Routing.....	56
Chapter 10 Maintenance	58
10.1 Time Settings	58
10.2 DDNS	58
10.3 Backup/Restore	60
10.4 Factory Default.....	61
10.5 Firmware Upgrade	62
10.6 Restart.....	62
10.7 Password	63
10.8 SysLog.....	64
 Appendix 1: Glossary	 65
Appendix 2: Features.....	Error! Bookmark not defined.
Appendix 3: Troubleshooting.....	66
Appendix 4: Contact Information.....	Error! Bookmark not defined.

Chapter 1 Product Overview

iBall Baton 150M Wireless-N Broadband Router complies with IEEE 802.11 b/g/n wireless standards.

Enhanced Wireless Transmission speed up to 150Mbps

Integrates 4- 10/100Mbps LAN ports & 1 - WAN port.

With Firewall security features as IP/MAC Filter and URL Filtering, NAT-Router and Wireless AP

Package Contents

The following items should be found in your package:

- 150M Wireless-N Broadband Router
- DC Power Adapter
- RJ45 Patch Cord
- Resource CD for 150M Wireless-N Router, including:
Easy Setup Wizard, Other Helpful Information

Product Feature:


- Complies with IEEE802.11b/g/n, IEEE802.3 & IEEE802.3u standards
- 4 -10/100M LAN ports, 1- WAN port & Wireless-N AP
- Operation Mode: AP Router / WDS
- Broadband Internet: PPPoE, Static IP, Dynamic IP connection type
- With Security feature such as IP, MAC and domain filtering
- With WEP, WPA-PSK, WPA2-PSK encryption security
- Built-in NAT, DHCP Server , Virtual server, DMZ and UPnP
- Web-based management
- 5dBi Omni-Directional Antenna
- Power Adapter: 9V DC, 0.6A

Conventions

The Router or iB-WRB150N mentioned in this guide stands for iBall Baton 150M Wireless-N Broadband Router without any explanation.

1.2 Panel Overview

LED overview:



LED	Status	Colour	Description
PWR	Blinking	Orange Led	Router is ON & functioning properly
SYS	Flashing	Green Led	Indicates as functioning properly
WPS	Blinking	Green Led	System is functioning properly
WLAN	Blinking	Orange Led	System is functioning properly
LAN	Blinking	Green Led	System is functioning properly
WAN	Blinking	Orange Led	System is functioning properly


Port/Button Overview:



Port/Button	Description
WAN	Internet port connecting to a DSL/Cable modem or ISP directly.
LAN	For connection to a computer or router.
RESET	Pressing this button for 7 seconds restores the device to factory default settings.
PWR	Power Adapter. Do not use a different power adapter than the included one.

Chapter 2 Installation

1. Connect one end of the included power adapter to the router and then plug the other end into a wall outlet nearby.
2. Connect the LAN port on the Router to the NIC port on your PC using an Ethernet cable.
3. Connect the WAN port on the Router to an Internet-enabled Cable/xDSL modem using an Ethernet cable.



4. Insert the included “Easy Setup Wizard” CD-ROM into your PC’s drive, click “Setup. exe” if the program does not run automatically and follow onscreen instructions to complete settings. Or directly launch a web browser and configure the router on web based utility (For details, refer to chapter 3).

150M Wireless-N Broadband Router (iB-WRB150N)



Chapter 3 Internet Connection Setup


3.1 Configure your PC's TCP/IP Settings

If you are using Windows XP operating system, do as follows.

1. Right click "My Network Places" and select "Properties".




2. Right click "Local Area Connection" and select "Properties"



3. Select "Internet Protocol (TCP/IP)" on the appearing window and

150M Wireless-N Broadband Router (iB-WRB150N)

click “Properties” button.




4. Select “Use the following IP address”


- **IP address:** Enter 192.168.1.xxx (xxx can be any value from 2~254).
- **Subnet mask:** Enter 255.255.255.0.
- **Default gateway:** Enter 192.168.1.1.
- **Preferred DNS server:** Enter 192.168.1.1 in case that you don't know the local DNS server address (Or contact your ISP for help).

At last, click OK to save your settings.


150M Wireless-N Broadband Router (iB-WRB150N)



If you are using Windows 7 operating system, do as follows:




1. Right click network icon on your desktop and then click the "Open Network and Sharing Center".




150M Wireless-N Broadband Router (iB-WRB150N)

2. Click “Change adapter settings”.




3. Right click “Local Area Connection” and select “Properties”




150M Wireless-N Broadband Router (iB-WRB150N)

4. Select “Internet Protocol (TCP/IP)” on the appearing window and click “Properties” button.



5. Select “Use the following IP address”



150M Wireless-N Broadband Router (iB-WRB150N)

- **IP address:** Enter 192.168.1.xxx (xxx can be any value from 2~254).
- **Subnet mask:** Enter 255.255.255.0.
- **Default gateway:** Enter 192.168.1.1.
- **Preferred DNS server:** Enter 192.168.1.1 in case that you don't know the local DNS server address (Or contact your ISP for help).


At last, click OK to save your settings.

3.2 Login to Router

1. With a Web-based utility, it is easy to configure and manage the iB-WRB150N 150Mbps Wireless -N Router.

To access the configuration utility, open a web-browser and type in the default address [http:// 192.168.1.1](http://192.168.1.1) in the address bar

1. 



Type password “**admin**” and then click ok to go to interface below:

Note: Web-based utility can be used on any Windows, Macintosh or UNIX OS with a Web browser, such as Microsoft Internet Explorer 8.0 / 9.0 (Suggested) & Mozilla Firefox.

3.3 Quick Internet Connection Setup

There are 2 Internet connection types on this screen, ADSL dialup (PPPoE) and Dynamic IP (DHCP).

PPPoE

Select PPPoE, if your ISP are using a PPPoE connection and enter the PPPoE user name and password provided by your ISP. Then setup a wireless security key on the interface below to secure your wireless network. At last, click the OK button to save your settings.

The screenshot shows a web interface with two main sections. The top section, titled "Internet Connection Settings", has a "Connection Type:" label followed by two radio buttons: "PPPoE" (which is selected) and "Dynamic IP". Below this is a link that says "For other connection types ,go to 'Advanced Settings'". The bottom section, titled "Wireless Security Settings", contains a "Security Key:" label followed by a text input field. At the bottom of the interface are two buttons: "Save" and "Cancel".

Dynamic IP

Select Dynamic IP as per your ISP details provided. We recommend you to setup a wireless security key on this interface to protect your wireless network from undesired access. Then click the OK button to save your settings.

This screenshot is similar to the one above but shows the "Dynamic IP" connection type selected. In the "Internet Connection Settings" section, the "Dynamic IP" radio button is now selected, while "PPPoE" is unselected. The rest of the interface, including the "Wireless Security Settings" section with the "Security Key:" input field and the "Save" and "Cancel" buttons, remains the same.

- The default Internet connection type is PPPoE. Contact your ISP if you are not clear about the PPPoE user name and password.
- Go to Chapter4 > WAN Settings, if you are using an Internet connection type other than the above- mentioned.

3.4 Quick Wizard

Click the quick wizard to configure the quickly the WAN settings & Wireless key.

- WAN Setup > you can configure PPPoE or Dynamic IP settings (Check for more settings as provided from ISP)
- Wireless > you can configure the WPA2-PSK Wireless security key to secure wireless connection.

The screenshot displays two sections of the router's web interface. The top section, titled "Internet Connection Settings", shows "Connection Type:" with two radio buttons: "PPPoE" (selected) and "Dynamic IP". Below this, a link states "For other connection types ,go to 'Advanced Settings'". The bottom section, titled "Wireless Security Settings", features a "Security Key:" label followed by a text input field. At the bottom of the interface are "Save" and "Cancel" buttons.

For more settings you can use the standard menu of advanced setup

Chapter 4 Network Settings

4.1 Status Info

This section allows you to view the router's WAN and system information.

WAN status:	
Connection status	Disconnected
WAN IP	
Subnet Mask	
Gateway	
Primary DNS	
Secondary DNS	
Connection type	Dynamic IP
Connection time	00:00:00
<input type="button" value="Release"/> <input type="button" value="Refresh"/>	

- **Connection Status:** Displays WAN connection status: Disconnected, Connecting or Connected.

Disconnected: Indicates that the Ethernet cable from your ISP side is not connected to the WAN port / connection problem of cable line.

Connecting: Indicates that the WAN port is correctly connected and is requesting an IP address from your ISP.

Connected: Indicates WAN port has been connected to your ISP.

- **WAN IP:** Displays WAN IP address.
- **Subnet Mask:** Displays WAN subnet mask.
- **Gateway:** Displays WAN gateway address.
- **Primary DNS:** Displays WAN primary DNS address.
- **Secondary DNS:** Displays WAN secondary DNS address.
- **Connection Type:** Displays current Internet connection type.

150M Wireless-N Broadband Router (iB-WRB150N)

System status:	
LAN MAC address	XX:XX:XX:XX:XX:XX
WAN MAC address	XX:XX:XX:XX:XX:XX
System time	2011-04-01 00:55:44
Running time	00:55:44
Connected client	1
Firmware Version	V1.0.0
Hardware version	V3.0

- **LAN MAC Address:** Displays router's LAN MAC address.
- **WAN MAC Address:** Displays router's WAN MAC address.
- **System Time:** Displays the time when system is updated.
- **Connected client:** Displays the number of connected computers (which obtains IP addresses from the device' DHCP server).
- **Software Version:** Displays router's firmware version.
- **Hardware Version:** Displays router's hardware version.

4.2 WAN

There are 5 Internet connection types available for your selection: PPPoE, Static IP, Dynamic IP, PPTP and L2TP. Select your Internet connection type and follow corresponding instructions below:

4.2.1 PPPoE

Select PPPoE, if your ISP are using a PPPoE connection and provide you with PPPoE user name and password information.

150M Wireless-N Broadband Router (iB-WRB150N)

Connection Type	PPPoE
User Name	<input type="text"/>
Password	<input type="password"/>
MTU Size (in bytes)	<input type="text" value="1492"/> (DO NOT modify it unless necessary, the default is 1492)
Service name	<input type="text"/> (Don't enter the information unless necessary.)
AC Name	<input type="text"/> (Don't enter the information unless necessary.)
Select the corresponding connection mode according to your situation.:	
<input checked="" type="radio"/> Connect Automatically	
<input type="radio"/> Connect on Demand	
Max.idle time <input type="text" value="60"/> (60-3600 Second)	
<input type="radio"/> Connect Manually	
<input type="radio"/> Connect on Time-based	
Note: The "Connect on Time-based" function goes into effect only when you have set the current time in "Time Settings" from "Maintenance".	
Connection time: from <input type="text" value="0"/> hours <input type="text" value="0"/> minutes to <input type="text" value="0"/> hours <input type="text" value="0"/> minutes	
<input type="button" value="Save"/> <input type="button" value="Cancel"/>	

- **Connection Type:** Displays current Internet connection type.
- **User Name:** Enter the user name provided by your ISP.
- **Password:** Enter the password provided by your ISP.
- **MTU:** Maximum Transmission Unit. DO NOT change it from the factory default of 1492 unless necessary. You may need to change it for optimal performance with some specific websites or application software that cannot be opened or enabled; in this case, try 1450, 1400, etc.
- **Service Name:** Description of PPPoE connection. Leave blank unless necessary.
- **AC Name:** Description of server. Leave blank unless necessary.
- **Connect Automatically:** Connects automatically to the Internet upon device startup or disconnection from the Internet.
- **Connect Manually:** Users need to connect the device to Internet manually upon disconnection from the Internet.
- **Connect on Demand:** Connects to Internet automatically upon traffic present.
- **Connect on Fixed Time:** Connects to Internet automatically within the specified time length.



Note:

To activate the "Connect on Fixed Time" feature, you must first configure current time on the "Time Settings" screen under "System Tools" menu.

4.2.2 Static IP

If your ISP offer you static IP Internet connection type, select "Static IP" from Mode drop-down menu and then enter IP address, subnet mask, Primary DNS and secondary DNS information provided by your ISP into corresponding fields.

Connection Type	Static IP
IP address	0.0.0.0
Subnet Mask	0.0.0.0
Default Gateway	0.0.0.0
Primary DNS	
Secondary DNS	(Optional)
MTU Size (in bytes)	1500 (DO NOT modify it unless necessary, the default is 1500)
<input type="button" value="Save"/> <input type="button" value="Cancel"/>	

- **Connection Type:** Displays the current Internet connection type.
- **IP Address:** Enter the WAN IP address provided by your ISP. Inquire your ISP if you are not clear.
- **Subnet Mask:** Enter WAN Subnet Mask provided by your ISP. The default is 255.255.255.0.
- **Default Gateway:** Enter the WAN Gateway provided by your ISP.
- **Primary DNS:** Enter the necessary DNS address provided by your ISP.
- **Secondary DNS:** Enter the secondary DNS address if your ISP provides, and it is optional.
- **MTU:** Maximum Transmission Unit. DO NOT change it from the factory default of 1500 unless necessary. You may need to change it for optimal performance with some specific websites or application software that cannot be opened or enabled.

4.2.3 Dynamic IP

Select this option if your ISP does not give you any IP information or account information. You don't need to configure any settings for this connection.

150M Wireless-N Broadband Router (iB-WRB150N)

Connection Type Dynamic IP

MTU Size (in bytes) (DO NOT modify it unless necessary, the default is 1500)

- **MTU:** Maximum Transmission Unit. DO NOT change it from the factory default of 1500 unless necessary. You may need to change it for optimal performance with some specific websites or application software that cannot be opened or enabled.

4.2.4 PPTP:

Connection Type PPTP

PPTP Server address

User Name

Password

MTU Size (in bytes)

Address mode Dynamic

IP address

Subnet Mask

Gateway

- **Connection Type:** Displays the current Internet connection type.
- **PPTP Server address:** Enter the IP address of a PPTP server.
- **Username/Password:** Enter Username/Password given by the PPTP server.
- **MTU:** Maximum Transmission Unit. DO NOT change factory default value unless necessary. However you may need to change it for optimal performance with some specific websites or application software that cannot be opened or enabled; in this case, try 1450, 1400, etc.

- **Address mode:** Select “Dynamic” if you don’t get any IP information from the PPTP server, otherwise select “Static”.
- **IP address:** Enter the IP address information provided by your ISP (PPTP server). Inquire your local ISP if you are not clear (Static IP address mode only).
- **Subnet mask:** Enter the subnet mask provided by your ISP, normally, 255.255.255.0 (Static IP address mode only).
- **Gateway:** Enter the gateway provided by your ISP (Static IP address mode only). Inquire your local ISP if you are not clear.

4.2.5 L2TP

Connection Type	<input type="text" value="L2TP"/>
L2TP Server address	<input type="text"/>
User Name	<input type="text"/>
Password	<input type="text"/>
MTU Size (in bytes)	<input type="text" value="1452"/>
Address mode	<input type="text" value="Dynamic"/>
IP address	<input type="text" value="0.0.0.0"/>
Subnet Mask	<input type="text" value="0.0.0.0"/>
Gateway	<input type="text" value="0.0.0.0"/>
<input type="button" value="Save"/> <input type="button" value="Cancel"/>	

- **Connection Type:** Displays the current Internet connection type.
- **L2TP Server address:** Enter the IP address of a L2TP server.
- **Username/Password:** Enter Username/Password specified by the PPTP server.
- **Address mode:** Enter the IP address information provided by your ISP (PPTP server). Inquire your local ISP if you are not clear (Static IP address mode only).
- **IP address:** Enter the IP address information provided by your ISP (PPTP server). Inquire your local ISP if you are not clear (Static IP address mode only).

150M Wireless-N Broadband Router (iB-WRB150N)

- **Subnet mask:** Enter the subnet mask provided by your ISP, normally, 255.255.255.0 (Static IP address mode only).
- **Gateway:** Enter the gateway provided by your ISP (Static IP address mode only). Inquire your local ISP if you are not clear.

4.3 LAN

Click “Advanced Settings”----“LAN Settings” to enter the interface below.

The screenshot shows the LAN Settings page. At the top, there is a navigation bar with tabs: Network Settings, Wireless Settings, DHCP, Virtual Server, Security Settings, Routing Settings, and Maintenance. Below this is a sub-navigation bar with tabs: Status Info, WAN, LAN (highlighted), MAC Clone, DNS, Bandwidth control, Traffic statistics, and WAN Speed. The main content area has a light orange background and contains the text: "This page is used to set the basic network parameters for LAN." Below this text are three input fields: "LAN MAC address" with a value of "xxxx:xx:xx:xx:xx:xx", "IP address" with a value of "192.168.1.1", and "Subnet Mask" with a value of "255.255.255.0". At the bottom right of the form are two buttons: "Save" and "Cancel".

- **LAN MAC Address:** Displays the router's LAN MAC address, which cannot be changed.
- **IP Address:** The default LAN IP address for this router is 192.168.1.1. You can change it according to your need.
- **Subnet Mask:** Enter the Router's LAN subnet mask. The default value is 255.255.255.0.



Note:

If you change the device's LAN IP address, you must enter the new one in your browser to get back to the web-based configuration utility. And LAN PCs' gateway must be set to this new IP for successful Internet connection.

4.4 MAC Clone

This section allows you to configure router's WAN MAC address. Some ISP may require binding an accepted MAC address for communication. If the bound MAC address differs from your router's predefined WAN MAC address, then you need to replace the router's WAN MAC with the bound MAC for achieving valid communication with your ISP.

The screenshot shows the router's web interface. At the top, there is a red navigation bar with tabs: Network Settings, Wireless Settings, DHCP, Virtual Server, Security Settings, Routing Settings, and Maintenance. Below this is a secondary navigation bar with links: Status Info., WAN, LAN, MAC Clone (highlighted in yellow), DNS, Bandwidth control, Traffic statistics, and WAN Speed. The main content area has a title 'MAC Address Clone'. Below the title is a red box containing the text 'MAC Address:' followed by a text input field with the placeholder 'XX:XX:XX:XX:XX:XX'. Below the red box are two buttons: 'Restore Default MAC' and 'Clone MAC Address'. At the bottom of the main area, there are two pairs of buttons: 'Save' and 'Cancel' for each of the two main buttons above.

- **MAC Address:** Configure router's WAN MAC address.
- **MAC Address Clone:** Clicking this button changes router's WAN MAC address from default to the MAC address of the PC you are currently on. Don't use this button unless your PC's MAC address is the one bound by your ISP.
- **Restore Default MAC:** Restores router's WAN MAC to default settings.

4.5 DNS

The Domain Name System (DNS) is a hierarchical naming system for computers, services, or any resource connected to the Internet or a private network. It functions just as the "phone book" for the Internet by translating human-friendly domain names into numerical identifiers of IP addresses for the purpose of locating and addressing these devices worldwide.

The screenshot shows the router's web interface with the 'DNS' tab selected under the 'Network Settings' menu. The interface includes a 'DNS setting' checkbox, 'Primary DNS' and 'Secondary DNS' input fields, and a 'Save' button. A note at the bottom states: 'Note: After the settings are completed, reboot the device to activate the modified settings.'

- **DNS Setting:** Check the box to enable DNS settings.
- **Primary DNS:** Enter the DNS server address provided by your ISP.
- **Secondary DNS:** Enter the secondary DNS address if your ISP offers you 2 DNS addresses (Optional).



Note:

1. Wrong DNS server addresses will lead to failure in accessing websites.
2. To activate the new settings, reboot the device.

4.6 Bandwidth Control

The bandwidth control feature can be used to simultaneously regulate traffic of up to 254 computers on your LAN network. It allows you to regulate a group of PCs' traffic by specifying a range of IP addresses.

- **Enable Bandwidth Control:** Check/uncheck the box to enable/disable bandwidth control. It is disabled by default.
- **IP Address:** Enter an IP address (same number in both boxes) or a range of IP addresses (different numbers in two boxes) of the PCs whose traffic you want to regulate.
- **Upload /Download:** You can select either to limit Uplink or Downlink Bandwidth of PCs within the specified IP range.
- **Bandwidth Range:** Maximum and minimum data flow which is permitted to be uploaded/downloaded by computers within a specified IP range. Unit is Kbytes/s. (For WAN bandwidth range, consult your ISP.)
- **Enable:** Check the box to enable current rule. The existing rule will not take effect when left unchecked.
- **Add to List:** Click it to add currently edited bandwidth control rule to the list.

For example: Suppose that you have a 2M WAN connection, then maximum

150M Wireless-N Broadband Router (iB-WRB150N)
download and upload rates in theory will be 2Mbps=256KByte/s and 512kbps=64KByte/s respectively. And you want the PC at the IP address of 192.168.1.100 to have 10-15KByte/s upload and 80-90KByte/s download rates.

Follow below step:

The screenshot shows the Baton 150M Wireless-N Broadband Router web interface. The top navigation bar includes links for Network Settings, Wireless Settings, DHCP, Virtual Server, Security Settings, Routing Settings, and Maintenance. Below this, a sub-navigation bar shows Status Info, WAN, LAN, MAC Clone, DNS, Bandwidth Control (highlighted), Traffic Statistics, and WAN Speed. The main content area is titled 'Bandwidth Control' and contains the following settings:

- Enable Bandwidth Control:** ☒ Enable
- IP address:** 192.168.1.100 ~ 100
- Upload/Download:** Upload (selected from a drop-down menu)
- Bandwidth range:** 15 ~ 10 (KByte/s)
- Enable:** ☐

Below these settings is an 'Add to list' button. At the bottom, there is a table with the following columns: No., IP segment, Destination, Bandwidth range, Enable, Edit, and Delete. Below the table are 'Save' and 'Cancel' buttons.

Step1. Enter 192.168.1.100 in IP address boxes.

Step2. Select Upload from the corresponding drop-down menu.

Step3. Enter 10~15 in bandwidth range box

Step4. Check the "Enable" box.

Step5. Click "Add to List".

Step6. Click "OK" to finish settings.

Then, follow steps above to add a download rule.

150M Wireless-N Broadband Router (iB-WRB150N)

Network Settings | Wireless Settings | DHCP | Virtual Server | Security Settings | Routing Settings | Maintenance

Status Info | WAN | LAN | MAC Clone | DNS | **Bandwidth control** | Traffic statistics | WAN Speed

Enable Bandwidth Control ☒ Enable

IP address: 192.168.1.105 ~ 105

Upload/Download: Upload

Bandwidth range: 40 ~ 50 (KByte/s)

Enable: ☒

Add to list

No.	IP segment	Destination	Bandwidth range	Enable	Edit	Delete
1	192.168.1.100~100	Upload	10~15	✓	Edit	Delete
2	192.168.1.101~101	Upload	20~30	✓	Edit	Delete

Save Cancel

For example: Supposing that you want PCs within the IP range of 192.168.1.2--192.168.1.254 to have 100-120KByte/s download rate and 20-30KByte/s upload rate, then repeat same settings shown on below screenshot on your router:

Network Settings | Wireless Settings | DHCP | Virtual Server | Security Settings | Routing Settings | Maintenance

Status Info | WAN | LAN | MAC Clone | DNS | **Bandwidth control** | Traffic statistics | WAN Speed

Enable Bandwidth Control ☒ Enable

IP address: 192.168.1.105 ~ 105

Upload/Download: Upload

Bandwidth range: 100 ~ 120 (KByte/s)

Enable: ☒

Add to list

No.	IP segment	Destination	Bandwidth range	Enable	Edit	Delete
1	192.168.1.100~100	Upload	10~15	✓	Edit	Delete
2	192.168.1.101~101	Upload	20~30	✓	Edit	Delete

Save Cancel

4.7 Traffic Statistics

Statistics dynamically displays bandwidth usage by PCs on your LAN.

150M Wireless-N Broadband Router (iB-WRB150N)

IP address	Uplink rate(KByte/s)	Downlink rate(KByte/s)	Sent message	Sent Bytes MByte	Received message	Received Bytes MByte
192.168.1.100	0.00	0.00	99	0.00	0	0.00
192.168.1.101	0.00	0.00	15	0.00	0	0.00

- **Enable Traffic Statistics:** Check the box to gather bandwidth usage by PCs on your LAN. It is disabled by default. Disabling this option may boost router's packet processing capacity. When enabled, system will dynamically renew statistics information every 5 seconds.
- **IP Address:** Displays IP address information of a corresponding statistics item.
- **Uplink Rate:** Displays how many Kbytes of data have been transmitted per second.
- **Downlink Rate:** Displays how many Kbytes of data have been received per second.
- **Sent Message (TX Packets):** Displays the total number of packets transmitted by a corresponding IP address through the router.
- **Sent Bytes:** Displays how many Mbytes of data have been transmitted by a corresponding IP address through the router.
- **Received Message (RX Packets):** Displays the total number of packets received by a corresponding IP address from the router.
- **Received Bytes:** Displays how many Mbytes of data have been received by a corresponding IP address from the router.

4.9 WAN Speed

This section allows you to configure WAN speed. Default settings are recommended.

150M Wireless-N Broadband Router (iB-WRB150N)

The screenshot shows the web interface of a Baton 150M Wireless-N Broadband Router. The top navigation bar includes links for Network Settings, Wireless Settings, DHCP, Virtual Server, Security Settings, Routing Settings, and Maintenance. Below this, a secondary bar shows Status Info, WAN, LAN, MAC Clone, DNS, Bandwidth Control, Traffic Statistics, and WAN Speed (which is highlighted). The main content area is titled 'Choose the WAN speed:' and contains five radio button options: AUTO (selected), 10M HALF-duplex, 10M FULL-duplex, 100M HALF-duplex, and 100M FULL-duplex. At the bottom of the form are 'Save' and 'Cancel' buttons.

- **AUTO:** DO NOT change this default setting unless you are connecting an excessively long Ethernet cable from your ISP, which may degrade drive capability, to the router's WAN port.
- **10M HALF-duplex:** Select it if your router's WAN port does not function properly when connected to an Ethernet cable from your ISP; excessive length of the cable may degrade drive capacity of the WAN port.
- **10M FULL -duplex:** Select it to set router's WAN port to work at 10Mbps in full duplex mode, improving WAN port drive capacity.
- **100M HALF-duplex:** Select it to set router's WAN port to work at 100Mbps in half duplex mode.
- **100M FULL-duplex:** Select it to set router's WAN port to work at 100Mbps in full duplex mode.

Chapter 5 Wireless Settings

5.1 Wireless Basic Settings

- **Enable Wireless function:** Check/uncheck to enable/disable the wireless feature. When disabled, all wireless related features will be disabled automatically
- **Wireless working Mode:** Select AP or WDS by clicking the corresponding radio button.
- **Network Mode:** Network Mode: Select a right mode according to your wireless client. The default mode is 11b/g/n mixed.
- **11Mbps 802.11b mode:** Select it if you have only Wireless-B clients in your wireless network.
- **54Mbps 802.11g mode:** Select it if you have only Wireless-G clients in your wireless network.
- **Mixed 802.11b/g mode:** Select it if you have only Wireless-B and Wireless-G clients in your wireless network.
- **Automatic 11b/g/n mixed mode:** Select it if you have Wireless-B, Wireless-G and Wireless-N clients in your wireless network.
- **SSID:** A SSID (Service Set Identifier) is the unique name of a wireless network. The primary SSID is changeable and compulsory.
- **Broadcast (SSID):** Select "Disable" to hide your SSID. When disabled, no wireless clients will be able to see your wireless network when they

perform a scan to see what's available. If they want to connect to your router, they will have to first know this SSID and then manually enter it on their devices. By default, this option is enabled.

- **Channel:** The Channel can be changed to fit the channel setting for an existing wireless network or to customize the wireless network. From the drop-down list, you can select a most effective channel, which ranges from 1 to 11. You can also select "Auto Select" to let system detect and choose one that best fits your network.

- **WMM-Capable:** Enabling this option may boost transmission capacity of wireless multimedia data (such as online video play).

- **ASPD Capable:** Auto power saving mode for WMM feature, disabled by default.

- **Channel Bandwidth:** Select a proper channel bandwidth to enhance wireless performance. When there are 11b/g and 11n wireless clients, please select the 802.11n mode of 20/40M frequency band; when there are only non-11n wireless clients, select 20M frequency band mode; when the wireless network mode is 11n mode, please select 20/40 frequency band to boost its throughput.

- **Extension Channel:** Indicates the working network frequency range for 11n mode.

- **WDS Mode:** To extend your existing wireless network coverage, select the WDS (Wireless Distribution System) feature.

150M Wireless-N Broadband Router (iB-WRB150N)

Wireless Basic Settings
Wireless Security
MAC Filtering
Connection Status

☒ Enable wireless function

Wireless Working Mode:
 ☐ Access Point (AP)
☒ WDS Bridge

Network Mode: Automatic(802.11b/g/n)

SSID:

Broadcast(SSID): ☒ Enable ☐ Disable

Channel:

Channel Bandwidth: ☐ 20 ☒ 20/40

Extension Channel:

WMM Capable: ☒ Enable ☐ Disable

APSD Capable: ☐ Enable ☒ Disable

Working Mode :WDS Bridge

AP MAC address:

AP MAC address:

- **AP MAC Address:** Enter the MAC address of a wireless link partner or populate this field using the Open Scan option.

Application example: Implement the WDS feature using 2 iB-WRB150N wireless router labeled iB-WRB150N-1 and iB-WRB150N-2.

1. Change the default wireless working mode of AP on iB-WRB150N to WDS as shown in the figure below:

☒ Enable wireless function

Wireless Working Mode:
 ☐ Access Point (AP)
☒ WDS Bridge

2. Add iB-WRH150N-2's MAC address to iB-WRH150N-1 and change iB-WRH150N-1's SSID and channel respectively to those of iB-WRH150N-2. (Assuming that iB-WRH150N-2's SSID is changed to OFFICE)

a. If you already know iB-WRH150N-2's MAC address, SSID and channel settings, then you can manually configure the same settings on iB-WRB150N-1.

150M Wireless-N Broadband Router (iB-WRB150N)

Wireless Basic Settings | Wireless Security | MAC Filtering | Connection Status

☒ Enable wireless function

Wireless Working Mode: ☐ Access Point (AP) ☒ WDS Bridge

Network Mode: Automatic(802.11b/g/n)

SSID: iB-WRH150N-2

Broadcast(SSID): ☒ Enable ☐ Disable

Channel: 2462MHz (Channel 11)

Channel Bandwidth: ☐ 20 ☒ 20/40

Extension Channel: 2442MHz (Channel 7)

WMM Capable: ☒ Enable ☐ Disable

APSD Capable: ☐ Enable ☒ Disable

Working Mode :WDS Bridge

AP MAC address: 80:3F:5D:80:8E:C8

AP MAC address:

b. Or you can use the Open Scan option.

- 1) Click the “Open Scan” button to display a list of available wireless networks.

Wireless Basic Settings | Wireless Security | MAC Filtering | Connection Status

☒ Enable wireless function

Wireless Working Mode: ☐ Access Point (AP) ☒ WDS Bridge

Network Mode: Automatic(802.11b/g/n)

SSID: iBall-Baton

Broadcast(SSID): ☒ Enable ☐ Disable

Channel: 2462MHz (Channel 11)

Channel Bandwidth: ☐ 20 ☒ 20/40

Extension Channel: 2442MHz (Channel 7)

WMM Capable: ☒ Enable ☐ Disable

APSD Capable: ☐ Enable ☒ Disable

Working Mode :WDS Bridge

AP MAC address:

AP MAC address:

Open scan

Save Cancel

150M Wireless-N Broadband Router (iB-WRB150N)

2) Select the iB-WRH150N-2's SSID from the list and click OK on the appearing dialogue box; iB-WRH150N-2's MAC address, SSID and channel settings will be automatically added to the iB-WRH150N-1

Wireless Basic Settings | Wireless Security | MAC Filtering | Connection Status

☒ Enable wireless function

Wireless Working Mode: ☐ Access Point (AP) ☒ WDS Bridge

Network Mode: Automatic(802.11b/g/n)

SSID: iB-WRH150N-1

Broadcast(SSID): ☒ Enable ☐ Disable

Channel: 2462MHz (Channel 11)

Channel Bandwidth: ☐ 20 ☒ 20/40

Extension Channel: 2442MHz (Channel 7)

WMM Capable: ☒ Enable ☐ Disable

APSD Capable: ☐ Enable ☒ Disable

Working Mode: WDS Bridge

AP MAC address: 80:3F:5D:80:8E:C8

AP MAC address:

Close scan

Select	SSID	MAC address	Channel	Security	Signal strength
<input checked="" type="radio"/>	iBall Wi-Fi	80:3F:5D:80:8E:C8	11	wep/wpa	64

3) Click OK to save your settings.

4) Configure wireless security settings. For this step, refer to section 5.2 hereof.

5) Repeat steps 1-4 on iB-WRH150N-2. After the 2 routers have added each other's MAC address and share the same SSID, channel, security settings and security key, the WDS feature can be implemented.



Note:

1. WDS feature can be implemented only between 2 wireless devices that both support the WDS feature. Plus, SSID, channel, security settings and security key must be the same on both devices. Using the Open Scan option and selecting link partner from the scan list automatically change the router's existing SSID and channel settings respectively to those of link partner as well as add link partner's MAC address. So we recommend you to use this Open Scan option for easy WDS settings.

2. Using WEP encryption improves WDS compatibility. For this reason, we recommend you to encrypt your wireless network with WEP when using the WDS feature.

5.2 Wireless Security

This section allows you to configure wireless security settings to block unauthorized access to your wireless network and prevent malicious packet sniffing. You have 4 ways to encrypt your wireless data: WPS, WEP, WPA-PSK and WPA2-PSK.

5.2.1 WPS Settings

Wi-Fi Protected Setup makes it easy for home users who know little of wireless security to establish a secure wireless home network, as well as to add new devices to an existing network without entering long passphrases or configuring complicated settings. Simply enter a PIN code or press the software PBC button or hardware WPS button (if any) and a secure wireless connection is established.

- **WPS Settings:** Select to enable/disable the WPS encryption. It is enabled by default.
- **WPS Mode:** Select PBC (Push-Button Configuration) or PIN.
- **PBC:** Click this software button or directly press the hardware WPS button on both your router and the new wireless client device (that you want to connect to your router wirelessly) for 1 second to establish an easy and secure wireless connection.
- **PIN:** To use this option you must know the PIN code from the wireless client. Simply click the PIN radio button and enter client's PIN code while using the same PIN code on client side for secure connection.
- **Reset OOB:** When clicked, the WPS LED will display a solid light; the WPS function will be disabled automatically; WPS server on the Router enters idle mode and will not respond to client's WPS connection request.

**Note:**

1. If you find the WPS LED blinking for 2 minutes after you select and apply the PBC mode, it means that the PBC encryption method is successfully enabled. And an authentication will be performed between your router and the WPS/PBC-enabled wireless client device during this time; if it succeeds, the wireless client device connects to your device, and the WPS LED displays a solid light thereafter. Repeat steps mentioned above if you want to connect more wireless client devices to your router.

2. The WPS function can be implemented only between your Router and another WPS-enabled device.

5.2.2 WPA-PSK

The WPA protocol implements the majority of the IEEE 802.11i standard. It enhances data encryption through the Temporal Key Integrity Protocol (TKIP) which is a 128-bit per-packet key, meaning that it dynamically generates a new key for each packet. WPA also includes a message integrity check feature to prevent data packets from being hampered with. Only authorized network users can access the wireless network.

Wireless Basic Settings **Wireless Security** MAC Filtering Connection Status

SSID -- "iBall-Baton"

Security Mode

WPA Algorithms ☒ AES ☐ TKIP ☐ TKIP&AES

Key

Key Renewal Interval Second

WPS Settings ☒ Disable ☐ Enable

- **Security Mode:** Select a proper mode, which is also supported by your wireless clients, from the drop-down menu.
- **WPA Algorithms:** Select either AES (advanced encryption standard) or TKIP (temporary key integrity protocol) type.
- **Key:** Enter a security key, which must be between 8-63 ASCII characters.
- **Key Renewal Interval:** Enter a valid time period for the key.

5.2.3 WPA2-PSK

The later WPA2 protocol features compliance with the full IEEE 802.11i standard and uses Advanced Encryption Standard (AES) in addition to TKIP encryption protocol to guarantee better security than that provided by WEP or WPA.

5.2.4 WEP

WEP is intended to provide data confidentiality comparable to that of a traditional wired network. Two methods of authentication can be used with WEP: Open System authentication and Shared Key authentication.

SSID -- "iBall-Baton"

Security Mode: Open

Default key: Key1

WEP key1: [] ASCII

WEP key2: [] ASCII

WEP key3: [] ASCII

WEP key4: [] ASCII

WPS Settings: ☒ Disable ☐ Enable

- **WEP Key:** You can select either ASCII or Hexadecimal from the drop-down menu.

Note: If you select ASCII, enter 5 or 13 valid ASCII characters; or if you select Hexadecimal, enter 10 or 26 Hexadecimal characters.

- **Default Key:** Select one key from the 4 preset keys.

5.3 MAC Filtering

The MAC filtering feature can be used to allow or disallow clients to connect to your wireless network.

150M Wireless-N Broadband Router (iB-WRB150N)

Network Settings Wireless Settings DHCP Virtual Server Security Settings Routing Settings Maintenance

Wireless Basic Settings Wireless Security **MAC Filtering** Connection Status

MAC address filter: Deny

Configure MAC address

MAC address

Add

Save Cancel

- **MAC Address Filter:** “Permit” means to permit PCs at specified MAC addresses to connect to your wireless network while “Forbid” means to block PCs at specified MAC addresses from connecting to your wireless network.
- **MAC Address:** Enter the MAC addresses of a wireless client and click “Add”.
- **MAC Address List:** Displays the MAC addresses added by you. You can delete any entry by clicking on the “Delete” button nearby.

Example 1:

To allow only a PC at the MAC address of 00:1e:a6:a4:56:75 to connect to your wireless network, do as follows:

Step1. Select “Permit” from MAC Address Filter drop-down menu.

Step2. Enter 00:1e:a6:a4:56:75 in the MAC address box.

Step3. Click the “OK” button to save your settings and you can add more MAC addresses, if you like, simply repeating the follow steps.

Network Settings Wireless Settings DHCP Virtual Server Security Settings Routing Settings Maintenance

Wireless Basic Settings Wireless Security **MAC Filtering** Connection Status

MAC address filter: Deny

Configure MAC address

MAC address

Add

00 1e a6 60 af b0

00:1e:a6:60:af:b0

Delete

Save Cancel

Example 2:


To prohibit only a PC at the MAC address of 00:1e:a6:67:d4:23 from connecting to your wireless network, follow steps above and make a few necessary changes as shown follow.

The screenshot displays the configuration interface of a 150M Wireless-N Broadband Router (iB-WRB150N). The top navigation bar includes tabs for Network Settings, Wireless Settings, DHCP, Virtual Server, Security Settings, Routing Settings, and Maintenance. The 'Wireless Settings' tab is selected, and the 'MAC Filtering' sub-tab is active. The 'MAC address filter' is set to 'Deny'. Below this, the 'Configure MAC address' section shows a table with columns for 'MAC address' and 'Operate'. The MAC address '00:1e:a6:67:d4:23' is entered in the input fields and is listed in the table with a 'Delete' button next to it. The 'Add' button is also visible. At the bottom, there are 'Save' and 'Cancel' buttons.

MAC address	Operate
00:1e:a6:67:d4:23	Delete

5.4 Connection Status

This interface displays the information of currently connected wireless clients including MAC addresses and bandwidth.



- **MAC Address:** Displays the MAC addresses of the PCs that have been wirelessly connected to your router.
- **Bandwidth:** Displays the channel bandwidth used by the currently connected hosts (connected wireless clients).



Note: "Bandwidth" refers to the wireless channel bandwidth instead of wireless connection rate.

Chapter 6 DHCP

6.1 DHCP Settings

The Dynamic Host Configuration Protocol (DHCP) is an automatic configuration protocol used on IP networks. If you enable the built-in DHCP server on the device, it will automatically configure the parameters of TCP/IP protocol for all your LAN computers (including IP address, subnet mask, gateway and DNS etc), eliminating the need for manual intervention. Be sure to set your computers to be DHCP clients by setting their TCP/IP settings to “Obtain an IP Address Automatically”. When you turn your computers on, they will automatically load the proper TCP/IP settings provided by the device.

- **DHCP Server:** Check or uncheck the box to enable or disable the device's DHCP server feature.
- **IP pool start address:** Enter the starting IP address for the DHCP server's IP assignment.
- **IP pool end address:** Enter the ending IP address for the DHCP server's IP assignment.
- **Lease Time:** The length of time for the IP address lease. Configuring a proper lease time improves the efficiency for the DHCP server to reclaim disused IP addresses.

6.2 DHCP Clients & Address Reservation

This section not only displays a DHCP dynamic client list but also includes a configurable Static DHCP assignment feature.

The DHCP client list displays IP addresses assigned by the built-in DHCP server, MAC addresses, host names and lease time. If you would like some devices on your network to always have fixed IP addresses, you can manually add a static DHCP assignment entry for each such device. You can manually add an IP address and a MAC address, and then whenever a host with this MAC address connects to the router, it will always get the same IP address (the one you just added). According to the connected computer's MAC address, the router checks relevant entries in its DHCP reservation list and decides what IP address to assign to this host (an unused IP from DHCP IP address pool, or a reserved one): If it fails in finding a reserved IP address for this MAC address in the list, it will immediately assign an unused IP from its DHCP IP address pool; and if such IP is found, it will be assigned to this host so as to ensure that host with a static DHCP assignment always get this reserved IP address.

Static assignment

IP Address: 192.168.1. [dropdown]

MAC address: [dropdown] [Add]

NO.	IP Address	MAC address	Delete
-----	------------	-------------	--------

[Refresh]

Host Name	IP Address	MAC address	Lease Time
Training	192.168.1.100	00:25:D3:32:BD:E1	00:00:20

[Save] [Cancel]

- **IP Address:** Enter the IP address for static DHCP assignment.
- **MAC Address:** Enter the MAC address of a computer to always receive the same IP address (the IP you just entered above).
- **Host name:** Displays the name of a computer (DHCP client).

- **Lease Time:** Remaining time for the corresponding IP address lease.

Chapter 7 Virtual Server

7.1 Port Forwarding

NO.	Start port-End port	LAN IP	Protocol	Enable	Delete
1.		192.168.1.	TCP	<input type="checkbox"/>	<input type="checkbox"/>
2.		192.168.1.	TCP	<input type="checkbox"/>	<input type="checkbox"/>
3.		192.168.1.	TCP	<input type="checkbox"/>	<input type="checkbox"/>
4.		192.168.1.	TCP	<input type="checkbox"/>	<input type="checkbox"/>
5.		192.168.1.	TCP	<input type="checkbox"/>	<input type="checkbox"/>
6.		192.168.1.	TCP	<input type="checkbox"/>	<input type="checkbox"/>
7.		192.168.1.	TCP	<input type="checkbox"/>	<input type="checkbox"/>
8.		192.168.1.	TCP	<input type="checkbox"/>	<input type="checkbox"/>
9.		192.168.1.	TCP	<input type="checkbox"/>	<input type="checkbox"/>
10.		192.168.1.	TCP	<input type="checkbox"/>	<input type="checkbox"/>

Well-known service ports: ID

- **Start/End Port:** Enter the service port range provided by the mapped host in internal network.
- **LAN IP:** The IP address of the computer which is used as a server in LAN.
- **Protocol:** Includes TCP, UDP and Both. Select “Both” when you are not sure about which protocol to use.
- **Enable:** Check the “Enable” option to activate the corresponding rule.
- **Delete:** Check the “Delete” option to delete the corresponding rule.

For example:

You want to share some large files with your friends who are not in your LAN; however it is not convenient to transfer such large files. Then, you can set up your own PC as a FTP server and use the port range forwarding feature to let your friends access these files. Provided that the static IP address of the FTP server (Namely, your PC) is 192.168.1.10 and

150M Wireless-N Broadband Router (iB-WRB150N)

you want your friends to access this FTP server through default port 21 and TCP protocol, then you can follow the steps below for configurations.

1. Enter 21 for both the start and end port in ID 1, or select "FTP" from "Well-Known Service Port" and port 21 will be added automatically to ID 1.
2. Enter 192.168.1.10 for the "IP Address", select "TCP" and then select "Enable".
3. The screenshot below displays the above settings.

The screenshot shows the 'Virtual Server' configuration page. At the top, there are tabs for Network Settings, Wireless Settings, DHCP, Virtual Server (selected), Security Settings, Routing Settings, and Maintenance. Below the tabs, there are sub-tabs for Port Forwarding (selected), DMZ, and UPnP. The main area contains a table with 10 rows for configuring virtual servers. The first row is highlighted with a blue border and contains the following data: NO. 1, Start port 21, End port 21, LAN IP 192.168.1.10, Protocol TCP, Enable checked, and Delete unchecked. Below the table, there is a 'Well-known service ports' section with a dropdown menu set to 'FTP(21)', an 'Add to' button, and an 'ID' dropdown set to '1'. At the bottom, there are 'Save' and 'Cancel' buttons, with the 'Save' button highlighted by a blue border.

NO.	Start port-End port	LAN IP	Protocol	Enable	Delete
1.	21-21	192.168.1.10	TCP	<input checked="" type="checkbox"/>	<input type="checkbox"/>
2.		192.168.1.	TCP	<input type="checkbox"/>	<input type="checkbox"/>
3.		192.168.1.	TCP	<input type="checkbox"/>	<input type="checkbox"/>
4.		192.168.1.	TCP	<input type="checkbox"/>	<input type="checkbox"/>
5.		192.168.1.	TCP	<input type="checkbox"/>	<input type="checkbox"/>
6.		192.168.1.	TCP	<input type="checkbox"/>	<input type="checkbox"/>
7.		192.168.1.	TCP	<input type="checkbox"/>	<input type="checkbox"/>
8.		192.168.1.	TCP	<input type="checkbox"/>	<input type="checkbox"/>
9.		192.168.1.	TCP	<input type="checkbox"/>	<input type="checkbox"/>
10.		192.168.1.	TCP	<input type="checkbox"/>	<input type="checkbox"/>

Well-known service ports: FTP(21) Add to ID 1

Save Cancel

4. Click "OK".

Now, your friends only need to enter ftp://xxx.xxx.xxx.xxx:21 in their browsers to access your FTP server. xxx.xxx.xxx.xxx is the device's WAN IP address. For example, if it is 172.16.102.89, then your friends only need to enter "ftp://172.16.102.89: 21" in their browsers.



Note: If you include port 80 on this section, you must set the port on remote (web-based) management section to a different number than 80, such as 8080, otherwise the virtual server feature may not take effect.

7.2 DMZ

In some cases, we need to set a computer to be completely exposed to extranet for implementation of a 2-way communication. To do so, we set it as a DMZ host.

- **DMZ Host IP Address:** Enter the IP address of a LAN computer which you want to set to a DMZ host.
- **Enable:** Check/uncheck to enable/disable the DMZ host.


For example: You can set a LAN computer at the IP address of 192.168.1.10 as a DMZ Host to intercommunicate with another host on the Internet.




Note: If you set a PC to a DMZ host, it will be completely exposed to extranet and gains no more protection from the device firewall.

7.3 UPnP

UPnP (Universal Plug and Play) allows a network device to discover and connect to other devices on the network. With this feature enabled, hosts in LAN can request the device to perform special port forwarding so as to enable external hosts to access resources on internal hosts.



- **Enable UPnP:** Check/uncheck to enable/disable the UPnP feature.

 **Note:** UPnP works in Windows XP, Windows ME or later (NOTE: Operational system needs to be integrated with or installed with Directx 9.0) or in an environment with installed application software that supports UPnP.

Chapter 8 Security Settings

8.1 IP Address Filtering

To better manage the computers in LAN, you can regulate LAN computers' access to certain ports on Internet using Client Filter functionality.

The screenshot shows the 'IP Address Filtering' configuration page. The top navigation bar includes 'Network Settings', 'Wireless Settings', 'DHCP', 'Virtual Server', 'Security Settings' (selected), 'Routing Settings', and 'Maintenance'. Below this, the sub-navigation bar shows 'IP Address Filtering' (selected), 'MAC Address Filtering', 'URL Filtering', and 'Remote Management'. The main configuration area has a light orange background and contains the following fields:

- Filter Mode:** A dropdown menu set to 'Allow'.
- Access Policy:** A dropdown menu set to '(1)'.
- Remark:** A text input field.
- Start IP:** A text input field with '192.168.1'.
- End IP:** A text input field with '192.168.1'.
- Port:** A text input field with a tilde (~) between two empty boxes.
- Type:** A dropdown menu set to 'TCP'.
- Time:** A time range selector showing '0:0' to '0:0'.
- Date:** A date range selector showing 'Sunday' to 'Saturday'.
- Enable:** A checked checkbox.
- Clear this item:** A 'Clear' button.
- Save/Cancel:** 'Save' and 'Cancel' buttons at the bottom.

- **Filter Mode:** Select Forbid only or Permit only according to your own needs.
- **Access Policy:** Select a number (indicating a filter rule) from the drop-down menu.
- **Remark:** Enter a meaningful name to yourself for a new filter rule.
- **Start /End IP Address:** Enter a starting/ending IP address.
- **Port:** Enter TCP/UDP protocol port number (s); it can be a range of ports or a single port.
- **Type:** Select a protocol or protocols for the traffic (TCP/UDP/Both).
- **Time:** Select a time range for the rule to take effect.
- **Day:** Select a day or several days for the rule to take effect.
- **Enable:** Check to enable or uncheck to disable a corresponding filter rule (allow/disallow matched packets to pass through router).

Example 1: To prohibit PCs within the IP address range of 192.168.1.100 -- 192.168.1.120 from accessing Internet from Monday to Friday, do as

follows:

Network Settings Wireless Settings DHCP Virtual Server Security Settings Routing Settings Maintenance

IP Address Filtering MAC Address Filtering URL Filtering Remote Management

Filter Mode:

Access Policy: (1)

Remark:

Start IP: 192.168.1.100

End IP: 192.168.1.120

Port: 1 ~ 5555

Type: TCP

Time: 0:00 ~ 0:00

Date: Sunday ~ Saturday

Enable: ☒ Clear this item:

- **Example 2:** To allow only the computer at an IP address of 192.168.1.145 to access Internet from 8:00 to 18:00 without restricting other computers in LAN, do as follow

Network Settings Wireless Settings DHCP Virtual Server Security Settings Routing Settings Maintenance

IP Address Filtering MAC Address Filtering URL Filtering Remote Management

Filter Mode:

Access Policy: (1)

Remark:

Start IP: 192.168.1.145

End IP: 192.168.1.145

Port: 80 ~ 80

Type: TCP

Time: 8:00 ~ 18:00

Date: Monday ~ Sunday

Enable: ☒ Clear this item:

8.2 MAC Address Filtering

To better manage the computers in LAN, you can use the MAC

Address Filter function to control the computer's access to Internet.

- **Filter Mode:** Select Forbid only or Permit only according to your own needs.
- **Access Policy:** Select a number (indicating a filter rule) from the drop-down menu.
- **Remark:** Enter a meaningful name to you for a new filter rule.
- **MAC address:** Enter the computer's MAC address that you want to filter out in the MAC address field.
- **Time:** Select a time range for the new MAC address filter rule to take effect.
- **Day:** Select a day or several days for the new MAC address filter rule to take effect.
- **Enable:** Check to enable or uncheck to disable a corresponding filter rule (allow/disallow matched packets to pass through router).

Example1: To prevent a PC at the MAC address of 00:E0:4C:69:A3:23 from accessing Internet within the time range of 8:00-18:00 from Monday to Friday, do as follows:

150M Wireless-N Broadband Router (iB-WRB150N)

Network Settings	Wireless Settings	DHCP	Virtual Server	Security Settings	Routing Settings	Maintenance
IP Address Filtering	MAC Address Filtering	URL Filtering	Remote Management			
<div>Filter Mode: Allow</div> <div>Access Policy: (1)</div> <div>Remark: <input type="text"/></div> <div>MAC address: 00 1E A6 44 35 69</div> <div>Time: 8 0 ~ 18 0</div> <div>Date: Monday ~ Friday</div> <div>Enable: <input checked="" type="checkbox"/> Clear this item: <input type="button" value="Clear"/></div> <div><input type="button" value="Save"/> <input type="button" value="Cancel"/></div>						

Example2: To allow only the PC at a MAC address of 00:1E:A6:44:35:69 to access Internet from Monday to Friday, do as follows:

Network Settings	Wireless Settings	DHCP	Virtual Server	Security Settings	Routing Settings	Maintenance
IP Address Filtering	MAC Address Filtering	URL Filtering	Remote Management			
<div>Filter Mode: Allow</div> <div>Access Policy: (1)</div> <div>Remark: <input type="text"/></div> <div>MAC address: 00 1E A6 44 35 69</div> <div>Time: 0 0 ~ 0 0</div> <div>Date: Monday ~ Friday</div> <div>Enable: <input checked="" type="checkbox"/> Clear this item: <input type="button" value="Clear"/></div> <div><input type="button" value="Save"/> <input type="button" value="Cancel"/></div>						

8.3 URL Filtering

To better control the LAN computers' access to websites, you can use URL filtering to allow or disallow their access to certain websites within a specified time range.

- **Filter Mode:** Select Disable or Forbid only according to your own needs.
- **Access Policy:** Select a number (indicating a filter rule) from the drop-down menu.
- **Remark:** Enter a meaningful name to you for a new filter rule.
- **Start/End IP Address:** Enter the starting/ending IP address.
- **URL character string:** Enter domain names or a part of a domain name that needs to be filtered.
- **Time:** Select a time range for the new URL filter rule to take effect.
- **Day:** Select a day or several days for the new MAC address filter rule to take effect.
- **Enable:** Check to enable or uncheck to disable a corresponding filter rule (allow/disallow matched packets to pass through router).

For example:

If you want to disallow all computers on your LAN to access “yahoo.com” at the time range of 8: 00-18: 00 from Monday to Friday, then do as follow.

150M Wireless-N Broadband Router (iB-WRB150N)

Network Settings	Wireless Settings	DHCP	Virtual Server	Security Settings	Routing Settings	Maintenance
------------------	-------------------	------	----------------	-------------------	------------------	-------------

IP Address Filtering MAC Address Filtering **URL Filtering** Remote Management

Filter Mode: Deny

Access Policy: (1)

Remark:

Start IP: 192.168.1.2

End IP: 192.168.1.254


URL character string: yahoo.com

Time: 8 0 ~ 18 0

Date: Sunday ~ Saturday

Enable: ☒ Clear this item: Clear

Save
Cancel

 **Note:** Each URL character string entry can corresponded to only a domain name. So you need to set multiple rules if you want to filter out multiple domain names.

8.4 Remote Management

The Remote Web-based Management feature allows users to configure your router from Internet via a web browser.

Network Settings	Wireless Settings	DHCP	Virtual Server	Security Settings	Routing Settings	Maintenance
------------------	-------------------	------	----------------	-------------------	------------------	-------------

IP Address Filtering MAC Address Filtering URL Filtering **Remote Management**

Enable ☒

Port: 8080

IP Address:

Save
Cancel

- **Enable:** Check or uncheck to enable or disable the remote web-based management feature.
- **Port:** Enter a port number for remote web-based management.
- **IP Address:** Enter the IP address of a PC on Internet authorized to access and manage your router's web-based utility remotely.



Note: If you enter 0.0.0.0 in the IP address box, then all PCs on Internet can access your router's Web-based utility to view or change your settings remotely once you enable the remote Web-based management feature.

For example: If you want to allow only a PC at the IP address of 218.88.93.33 to access your router's web-based utility from Internet via port: 8080, you need to configure same settings shown in the diagram above on your router. And what this IP user needs to do is to simply launch a browser and enter `http://220.135.211.56:8080` (provided that your router's WAN IP address is 220.135.211.56).

Network Settings Wireless Settings DHCP Virtual Server Security Settings Routing Settings Maintenance

IP Address Filtering MAC Address Filtering URL Filtering Remote Management

Enable ☒

Port 8080

IP Address 220.135.211.56

Save Cancel

- **Destination Network IP Address:** Enter a destination IP address or subnet.
- **Subnet Mask:** Enter a Subnet Mask that corresponds to destination IP address or subnet you entered.
- **Gateway:** Next-hop IP address.



Note:

1. Gateway IP address must be on the same subnet with the router's LAN/WAN IP address.
2. If you want destination network to be a single host, then you must enter an IP address thereof and 255.255.255.255 respectively in Destination Network IP Address and Subnet Mask boxes.
3. If you want destination network to be a network, then you must enter an IP address and a corresponding subnet mask value respectively in Destination Network IP Address and Subnet Mask boxes. For example, if you enter 10.0.0.0 in the IP address box, then corresponding subnet mask should be 255.0.0.0.

Chapter 10 Maintenance

10.1 Time Settings

This section assists you in setting the device's system time; you can either select to set the time and date manually or automatically obtain the GMT time from Internet.

Note: The configured time settings lose once the router is powered off. But it obtains the GMT time automatically when you connect it to the Internet. Features/functions based on time (e.g. security settings) take effect only after time settings are configured manually or updated automatically from Internet.

10.2 DDNS

Dynamic DNS or DDNS is a term used for the updating in real time of Internet Domain Name System (DNS) name servers. We use a numeric IP address allocated by Internet Service Provider (ISP) to connect to Internet; the address may either be stable ("static"), or may change from one session on the Internet to the next ("dynamic"). However, a numeric address is inconvenient to remember; an address which changes unpredictably makes connection impossible. The DDNS provider allocates a static hostname to the user; whenever the user is allocated a new IP address this is communicated to the DDNS provider by software running on a computer or network device at that address; the provider distributes the association between the hostname and the address to the Internet's DNS servers so that they may resolve DNS queries. Thus, uninterrupted access to devices and services whose numeric IP address may change is maintained.

150M Wireless-N Broadband Router (iB-WRB150N)

Network Settings Wireless Settings DHCP Virtual Server Security Settings Routing Settings Maintenance

Time Settings DDNS Backup/Restore Factory Defaults Firmware Upgrade Restart Password Syslog

DDNS Service ☒ Enable ☐ Disable

Service Provider no-ip.com [Sign up](#)

Username Admin

Password 12345678

Domain Name domain

Save Cancel


- **DDNS Service:** Click Enable or Disable radio button to enable/disable the DDNS feature.
- **Service Provider:** Select your DDNS service provider from the drop-down menu (DynDNS or no-ip).
- **Username:** Enter the DDNS username provided by your DDNS service provider.
- **Password:** Enter the DDNS password provided by your DDNS service provider.
- **Domain Name:** Enter the DDNS domain name distributed by your DDNS service provider.

Username	Admin
Password	12345678
Domain Name	domain.no-ip.com


For example: If you have registered a DDNS service in no-ip.com and are allocated with domain, 12345678, domain.no-ip.com respectively as username, password and domain name for a web server on your PC at 192.168.1.10, then configure port settings on port range forwarding interface under virtual server menu and enter this information on the above DDNS interface. Others can access your web server by simply entering <http://domain.no-ip.com> in their browser address bar.

10.3 Backup/Restore

This section allows you to backup current settings or to restore the previous settings configured on the device.




- **Backup** : Once you have configured the device the way you want it, you can save these settings to a configuration file on your local hard drive that can later be imported to your device in case that the device is restored to factory default settings. To do this, click the “Backup” button next to where it says “Select the file directory to save the configured parameters” on the screen above.




And then, click the “Save” button on the appearing screen above to store it under the selected path.

- **Restore** : Click the "Browse" button to locate and select a configuration file that is saved previously to your local hard drive.

150M Wireless-N Broadband Router (iB-WRB150N)




And then click the "Restore" button to reset your device to previous settings.



10.4 Factory Default


To restore all settings to the device's factory default values, click the "Restore to Factory Default" button on the interface below:



Note: To activate your settings, reboot the device after you reset it.

10.5 Firmware Upgrade

Firmware upgrade is released periodically to improve the functionality of your device and also to add new features. If you run into a problem with a specific feature of the device, log on to our website (www.iBallBaton.com) to download the latest firmware to update your device.



The screenshot shows the 'Firmware Upgrade' page. At the top, there is a navigation bar with tabs: Network Settings, Wireless Settings, DHCP, Virtual Server, Security Settings, Routing Settings, and Maintenance. Below this is a sub-navigation bar with links: Time Settings, DDNS, Backup/Restore, Factory Defaults, Firmware Upgrade (highlighted), Restart, Password, and Syslog. The main content area has an orange background and contains the following text:

By upgrading the router's software, you'll get new features.

Select the firmware file:

No file selected.


Current system version: V1.0.0; Publishing date: Apr 11 2013

Note: Don't power off the router while upgrading, otherwise, the router will be damaged and can not be used. After successfully upgraded, the router will reboot automatically. The upgrading process takes a few minutes, please wait!

- **Browse:** Click this button to select an upgrade file.
- **Upgrade:** Click this button to start an upgrading process. After the upgrade is completed, the Router will reboot automatically.

10.6 Restart

By Rebooting the device, new settings can be brought into effect. And WAN connection will be cut automatically during this process.




The screenshot shows the 'Restart' page. At the top, there is a navigation bar with tabs: Network Settings, Wireless Settings, DHCP, Virtual Server, Security Settings, Routing Settings, and Maintenance. Below this is a sub-navigation bar with links: Time Settings, DDNS, Backup/Restore, Factory Defaults, Firmware Upgrade, Restart (highlighted), Password, and Syslog. The main content area has an orange background and contains the following text:

Click this button and the router will restart.

Below the button is a long, empty text input field.

10.7 Password

This section allows you to change login password for accessing device's Web-based interface.



The screenshot shows the 'Password' page in the router's web interface. The top navigation bar includes 'Network Settings', 'Wireless Settings', 'DHCP', 'Virtual Server', 'Security Settings', 'Routing Settings', and 'Maintenance'. Below this, a secondary bar contains 'Time Settings', 'DDNS', 'Backup/Restore', 'Factory Defaults', 'Firmware Upgrade', 'Restart', 'Password' (highlighted), and 'Syslog'. The main content area has an orange background and contains the following text: 'On this page, you can change the administrator's password.' followed by 'Note: Password can only consist of letters and numbers.' There are three input fields: 'Old password', 'New password', and 'Confirm new password'. At the bottom, there are 'Save' and 'Cancel' buttons.


- **Old Password:** Enter the old password.
- **New Password:** Enter a new password.
- **Confirm new Password:** Re-enter the new password for confirmation.
- **OK:** Click it to save your new password.



Note: It is highly recommended that you change default login password.

10.8 SysLog

The Syslog option allows you to view all events that occur upon system startup and check whether there is attack present in your network.



- **Refresh:** Click this button to update the log.
- **Clear:** Click this button to clear the log record.

Appendix 1: Glossary

Channel

A communication channel, also known as channel, refers either to a physical transmission medium such as a wire or to a logical connection over a multiplexed medium such as a radio channel. It is used to transfer an information signal, such as a digital bit stream, from one or more transmitters to one or more receivers.

If there are several APs coexisting in the same area, it is recommended that you configure a different channel for each AP to minimize the interference between neighboring APs. For example, if 3 American-standard APs (i.e. adopts 11 channels) coexist in one area, you can setup their channels respectively to 1, 6 and 11 to avoid mutual interference.

SSID

Service set identifier (SSID) is used to identify a particular 802.11 wireless LAN. It is the name of a specific wireless network. To let your wireless network adapter roam among different APs, you must set all Aps' SSID to the same name.

WPA/WPA2

The WPA protocol implements the majority of the IEEE 802.11i standard. It enhances data encryption through the Temporal Key Integrity Protocol (TKIP) which is a 128-bit per-packet key, meaning that it dynamically generates a new key for each packet. WPA also includes a message integrity check feature to prevent data packets from being hampered with. Only authorized network users can access the wireless network.

The later WPA2 protocol features compliance with the full IEEE 802.11i standard and uses Advanced Encryption Standard (AES) in addition to TKIP encryption protocol to guarantee better security than that provided by WEP or WPA.

Appendix 3: Troubleshooting

1. **Q:** I entered the device's LAN IP address in the web browser but cannot access the utility. What should I do?

A: 1) Verify whether the device functions correctly. Sys LED should blink several seconds after you power on the device. If not, then internal malfunction may have occurred; Please contact our technical support for help.

2) Verify physical connectivity by checking if corresponding port's link LED lights up. If not, try a different cable.

3) Click "Start" -- "Run", enter "cmd" and then "ping 192.168.1.1" on appearing CLI to diagnose whether your PC has connected to the device or not. If ping succeeds, then check whether the Proxy Server feature is enabled on your browser. If enabled, disable it immediately. In case that ping fails, press and hold the "RESET" button on your device for over 7 seconds to restore factory default settings, and then run "ping 192.168.1.1" again.

4) Contact our technical support for help if the problem still exists after you tried all the above.

2. **Q:** I forget the login password to my device, what should I do?

A: In this case, you need to restore your device to factory default settings. To do so, Press the hardware button RESET on your device for about 7 seconds and then release.

3. **Q:** My computer shows an IP address conflict error after having connected to the device. What should I do?

A: 1) Check if there are other DHCP servers present in your LAN. If there are other DHCP servers except your router, disable them immediately.

2) The default IP address of the device is 192.168.1.1; make sure this address is not used by another pc or device. In case that two computers or devices share the same IP addresses, change either to a different address.

4. **Q:** I cannot access Internet and send/receive emails; what should I do?

A: This problem mainly happens to users using ADSL dialup or dynamic IP internet connection types. In this case, go to “WAN Settings” to change the MTU value from default 1492 to 1450 or 1400, etc.

5. **Q:** How do I share resources on my computer with users on Internet through the device?

A: To let Internet users access internal servers on your LAN such as e-mail server, Web, FTP, via the device, use the “Virtual Server” feature. To do so, follow steps below:

Step 1: Create your internal server, make sure the LAN users can access these servers and you need to know related service ports, for example, Web server’s port is 80; FTP is 21; SMTP is 25 and POP3 is 110.

Step 2: Click “Virtual Server” and select “Port Forwarding” on the Router’s web interface.

Step 3: Input the external service port ID, for example, 80.

Step 4: Input the internal Web service port ID, for example, 80.

Step 5: Input the internal server’s IP address. For example, if your Web server’s IP address is 192.168. 1.10 please input it.

Step 6: Select a communication protocol used by your internal host: TCP, UDP or ICMP.

Step 7: Click “OK” to activate the settings.

Server	Protocol	Service Port ID
WEB Server	TCP	80
FTP Server	TCP	21
Telnet	TCP	23
NetMeeting	TCP	1503, 1720
MSN Messenger	TCP/UDP	File Send: 6891-6900(TCP) Voice:1863, 6901(TCP) Voice:1863, 5190(UDP)
PPTP VPN	TCP	1723
Iphone5.0	TCP	22555
SMTP	TCP	25
POP3	TCP	110

COPYRIGHT & TRADEMARKS

Specifications are subject to change without notice. iBall Baton is a registered trademark of Best IT World (India) Pvt. Ltd. Other brands and product names are trademarks or registered trademarks of their respective holders.

No part of the specifications may be reproduced in any form or by any means or used to make any derivative such as translation, transformation, or adaptation without permission from Best IT World (India) Pvt. Ltd. All rights reserved.

Note: For any technical help on iBall Baton products please contact support@iballbaton.com

www.iBallBaton.com